




# Automation Systems® AUSTRALIA

## Premier SW24T

Advanced Digital Swing Gate Controller



Designed & Engineered



In Italy



Tuya Smart  
Compatible



Step by Step Simple  
Installation  
Guide on Page 2




**Photocell must be used to assist accident prevention.  
Not installing photocells is a safety risk.**


# Table of Contents

1	Specifications, Dimension and Tools Required
2	Step By Step Installation Guide
3	Installation Layout/Wiring Layout
4	Controller Layout and Display Screen Status
5	Gate Motor Operating Logic, Internal Limit Switched (Series) motor Connection Brief
6	No limit Switch and External Limit Switch Motor Connection Brief
7	CERO/CERO M10 Standalone Solar System Connection
8	Battery Backup Connection, Power Transformer Connection
9	DECEL and OBST.F Trim pot Adjustments, System Menu Hierarchy
10	Basic Menu (operating logic)
11	Basic Menu continued (remote/wireless learning, automatic closing time, working time learning and Motor Test)
12	Core Menu (manual time adjustments, single gate mode, defaulting, release torque)
13	Core Menu continued (direct limit, opening edge, closing edge, photocell, stop)
14	Core Menu continued (kickback stroke, soft start, series limit switch, receiver mode, automatic lock)
15	Core Menu continued (special detector, light mode)
16	Remote Learning (detailed)
17	Remote Usage, Enrolment, Wireless Keypad Learning (detailed)
18	Automatic Closing Timer and Optional TSL1 Mobile APP Module connections
19	Motor Test
20	Learn Time for Double Gates
21	Learn Time for Single Gates
22	Advanced Learn Time for Double and Single Gates
23	Photocells
24	Special Detector/Secondary Photocells
25	Fortress Automatic Locks
26	Tekno Wi-Fi Switch, Loop Detector, Digital Weekly Timer
27	Tekno K1 Wired Keypad, E Loop, Light Output
28	Tekno S1 (4G) Module, Wired Push Button/Emergency Stop, Antenna
29	Fill In Enrolment List
30	Warranty Terms


## Tools Required




2/2.5mm Flat Head for Terminal Connections




#1 Phillips Head or Bit (130mm length min.) Fixing to wall/post



Multi Meter (not essential)



Wire Stripper




Drill and Drill Bits


## Specifications

Operating Voltage	24V AC/24V DC
Standby Consumption	~20mA
Battery Backup Support	Yes
Motor Outputs	TWO (Total Max. 12A)
Motor Limit Support	Direct to PCB, Wired In series and No Limits
Automatic Lock Support	YES, Electric and Magnetic Locks (24V) (Max. 2A)
Warning Light Output	Yes (Max 1A)
Accessories Power	12V DC (250mA)
Safety Inputs	Photocell, Detector, Safety Edge
Operation Temperature	-10°C to +60°C
Remote Button Capacity	192
Duty Cycle	70%


## Dimensions



# Step by Step Installation Guide




# Installation Layout



Number	Accessory	Requirements
A	Gate Controller	Power by mains, outdoor transformer or Solar
C	Entry Keypad	Dex 4 (wireless), All others wired to gate controller by 4 core cable
D	Exit Keypad	Dex 4 (wireless), All others wired to gate controller by 4 core cable
E	Driveway Ground Stop	Double Swing Gates Only, Single Swing Gate should have stop on gate post
F	Induction Loop/E Loop	Induction Loop: Housed inside gate controller with 1 core cable for the driveway loop. E Loop: E Trans Housed in control box. Wireless to E Loop.
G	Photocell Transmitter	No cable required for Dukie XR (Reflector), No Cable for Battery Powered TX, Dukie X requires 2 core Cable to gate controller
H	Photocell Receiver	4 Core cable to gate controller
I	Gate Controller Power Source	Mains, Outdoor Transformer or Solar Battery System to the Gate Controller
J	Motor "2"	Master Motor (First to Open) - Check Manual for Wiring Requirements
K	Motor "1"	Slave Motor (NOT USED SINGLE GATE) - Check Manual for Wiring Requirements
L	Automatic Lock	2 core cable to gate controller
M	ADDITIONAL Photocell Transmitter	No cable required for Dukie XR (Reflector), No Cable for Battery Powered TX, Dukie X requires 2 core Cable to gate controller
N	ADDITIONAL Photocell Receiver	Optional Additional Safety Device, 4 Core cable to gate controller
O	Warning Light	2 core cable to gate controller

# Controller Layout



- 1. Antenna
- 2. ANT GND

- 3. Start/Open Input (N/O)
- 4. Pedestrian/Close Input (N/O)
- 5. COMMON to 3,4,6,7
- 6. Photocell Input (N/O or N/C)
- 7. Special Detector
- 8. OP Edge/LSO-1 (open edge device or DIRECT LIMIT M1 Open)
- 9. CL Edge/LSC-1 (close edge device or DIRECT LIMIT M1 Close)
- 10. LSO-2 DIRECT LIMIT M2 Open
- 11. LSC-2 DIRECT LIMIT M2 Close
- 12. COMMON to 8,9,10,11
- 13. STOP Input (N/O or N/C)
- 14. COMMON to 13
- 15. **+12V DC OUTPUT** for Accessories (Regulated)
- 16. **-12V DC OUTPUT** for Accessories
- 17. Lock Output + (Not Regulated)
- 18. Lock Output -
- 19. Light Output + (Not Regulated)  
LPW+ (Photocell Power in solar Mode)
- 20. Light Output -  
LPW- (Photocell Power in solar Mode)
- 21-22. M1 Terminal (SLAVE)
- 23-24. M2 Terminal (MASTER/SINGLE GATE)

# Display Screen Status

## General

- Standby
- Opening  
*Fast Speed 0.5 Second Flash*  
*Slow Speed 1 Second Flash*
- Closing  
*Fast Speed 0.5 Second Flash*  
*Slow Speed 1 Second Flash*
- Battery Backup Mode/Low Input Power (Flashes)
- Automatic Closing Countdown Timer


## Safety Status

- Photocell Input Active
- STOP Input Active
- Photostop Input Active (Special Detector)
- Detector Input Active (Special Detector)
- Edge Input Active (Opening Edge)
- Edge Input Active (Closing Edge)

## Operating Input Status

- Start Input Active  
Operating Logic
- Pedestrian Input Active  
Operating Logic
- Open Input Active  
Operating Logic
- Close Input Active  
Operating Logic

# Gate Motor Logic



## Internal SERIES Limit Switch Gate Motor Connection

COMMANDO, BANDIT, DINGO Series Motors


Limit Switch controller embedded within the gate motor passing power through the micro switches in a series circuit.




Limit Switches in SERIES to Motor



Feature is enabled and ready to detect limits.



Refer to gate motor installation manual for correct wiring  
 this is an example only



When a gate motor is without limit switches.




Limit Switches in SERIES to Motor



Feature is disabled and ready to detect by over current.


Refer to gate motor installation manual for correct wiring  
this is an example only



## External Wiring Limit Gate Motor Connection (5/6 Wire Gate Motors)

Raptor Series Motors

Directly wired micro switches back to the gate controller.



### OPEN POSITION SWITCH

Open Switch Terminal 10 (Motor 2)  
Open Switch Terminal 8 (Motor 1)

### CLOSED POSITION SWITCH

Close Switch Terminal 11 (Motor 2)  
Close Switch Terminal 9 (Motor 1)

**BOTH** Micro Switch Commons Terminal 12



Direct to control board Limit Switches (NOT in series to motor)


**nc** Sets the controller to accept NORMALLY CLOSED limit switches directly to the control board limit switch terminals

**no** Sets the controller to accept NORMALLY OPEN limit switches directly to the control board limit switch terminals




Limit Switches in SERIES to Motor

**nt** Feature is disabled, Used for over current motors OR motors requiring the Limit Switches wired DIRECTLY to the controller



Refer to gate motor installation manual for correct wiring  
this is an example only



# CERO/CERO M10 Standalone Solar System Connection


A standalone solar system is a totally off grid solution used for green energy initiatives or simply when its not possible to run power to the gate system. To conserve power constant power draw devices such as wired keypads and magnetic locks are not to be used. The alternatives are wireless keypads (use there own batteries) and electric locks (only powered for two seconds per cycle).




ALWAYS Connect the Solar Panel AFTER the batteries to ensure the system can Auto-Detect the voltage configuration.

## Batteries Connections

### Step 1: Connect the Batteries First




### Step 2: Connect the Solar Panel Second





### Step 3: Connect the Load/Control board Output Last

Charge controller output is OFF and terminal block is unplugged for wiring works.

CERO M10 "▲" Turns ON/OFF the Output  
CERO "SET" button Turns ON/OFF the Output




INPUT Terminal  
Positive on RIGHT SIDE (+)  
Negative on LEFT SIDE (-)



## Battery Backup Connection

The battery backup will allow for uninterrupted usage in case of a power disruption. The battery backup system can operate the gate for a period of 4-6 hours during the power disruption. Once the power is restored the system will automatically recharge the battery system ready for the next use.


**Note:** When in battery backup mode the slowdown is disabled automatically to overcome any difference in speed.



To connect the battery backup simply plug the two pin connector in the correct orientation into the battery port on the controller whilst the board is powered by mains.


## Multi Output Toroidal Transformer (Internal)

The transformer on a mains powered system is the primary source of power, it takes the high voltage input and transforms to low voltage which is connected to the controller. By default the controller uses the lower of the two outputs (white wire) which is typically suggested for most gate installs however incase required due to environmental forces it would be suggested to swap the lower output (green wire) for the higher output (yellow wire).




## Outdoor Low Voltage Weatherproof Transformer (OT-24)

Where a power point is not available at the gate the Outdoor Transformer is used as the primary source of power, it takes the high voltage input and transforms to low voltage which is connected to the controller through the low voltage extension cable for a maximum distance of 100 metres.




## “Decel” Slow Speed/De-acceleration Adjustment



DECCEL

The “De-acceleration” Trim pot is the slow speed trimmer allowing a fine tuning of the SLOW Speed portion of the operating cycle, Typically adjustment range is 20% to 50% from the slowest speed (minimum) depending on gate size, weight and inertia.



## “OBST.F” Obstruction/Overcurrent Adjustment




OBST.F

The “Obstruction Force” Trim pot is the pressure sensing adjustment before the controller recognises cut-off. Gate and Environmental factors will determine how high or low to adjust based on gate weight, wind resistance and the required power to operate the motor.

**Setting too high will affect how quickly the controller will shut off under load, accident or at all, If set too high motor(s) may not shut off at all - Do not set too high.**


setting too low can cause the controller to shut off too early (too sensitive) and cause intermittent operations.



## System Menu Hierarchy

Throughout the manual to simplify identification the two preliminary menus will be displayed with a coloured background as illustrated below, any sub-menus and exit will be displayed with a grey background.

Whilst gates are OPEN,  
FROM STANDBY **HOLD UP**  
and an automatic  
gate calibration will be  
initiated. Release the UP  
button when  
the gate begins to close.



EXIT will take you back one level

From preliminary menus it will return to standby

From any setting menu it will cancel the change and return you to the preliminary menu



If in a setting adjustment and you wish to cancel press UP and DOWN together momentarily to return back one level.

If in a preliminary menu it will function the same as scrolling to exit.





## Setting the system Operating Logic (Default Standard)

- 
**Standard**  
 Operates OPEN/CLOSE by remote and/or wired-wireless accessories
- 
**Standard WITH Automatic Closing Timer** [Adjust the Automatic Closing Timer in 5P menu](#)  
 Operates OPEN remote and/or Wireless Accessories with an automatic closing timer (can still be closed earlier by remote and/or wired-wireless accessories)  
 Timer can be cancelled using the STOP feature
- 
**Typical Complex**  
 Operates OPEN/CLOSE by remote and/or wired-wireless accessories with the WIRED input terminals switching to loop detector mode OPEN Terminal and CLOSE Terminal
- 
**Typical Complex WITH Automatic Closing Timer** [Adjust the Automatic Closing Timer in 5P menu](#)  
 Operates OPEN/CLOSE by remote and/or wired-wireless accessories with the WIRED input terminals switching to loop detector mode OPEN Terminal and CLOSE Terminal along with an automatic closing timer (can still be closed earlier by remote and/or wired-wireless accessories)  
 Timer can be cancelled using the STOP feature
- 
**Secure Complex Mode WITH Automatic Closing** [Adjust the Automatic Closing Timer in 5P menu](#)  
 Ignores additional commands during opening, Can latch a timer circuit to hold the gate open, automatic closing by unlatching a timer (allows auto close timer countdown to begin), no other methods to close.

Wired Input Terminals		Operating Logic	Remote Channels	
Terminal 3 (ST/OP)	Terminal 4 (PD/CL)			
OPEN /STOP/ CLOSE	<u>Ped.</u> OPEN /STOP/ CLOSE		OPEN /STOP/ CLOSE	<u>Ped.</u> OPEN /STOP/ CLOSE
OPEN	CLOSE		OPEN	CLOSE
OPEN	CLOSE		OPEN	CLOSE
OPEN	N/A		OPEN	PED. Open

"OPEN" only commands always restart an automatic closing timer (if applicable).  
 any "STOP" command by remote control always cancels the automatic closing timer (if applicable).  
 any "CLOSE" command will bypass the automatic closing timer (if applicable) and close the gate.

**Lc** Remote, Wireless button and Wireless Keypad Learning/Deleting  
Detailed Page 16 & 17

- **c1** C1 Command (Full Gate Operation)
- **c2** C2 Command (Pedestrian/Partial Gate Operation)
- **rt** Delete WITH the wireless component present
- **rn** Delete by memory position
- **ra** Delete the entire memory (format)

**Lt** Learn Working Times

- **Au** Automatic Learning (Universal one direction)
- **nn** Manual Learning
- **bd** Automatic Learning (Independent Directions)

**SP** Automatic Closing Time (Default 10 seconds)

- **99** Only valid when using an OPERATION LOGIC **oL** that uses automatic closing  
**01**= Immediate Close  
**2-299**= Delayed automatic Closing Time by the set value in Seconds

**FS** Fast Speed Voltage Adjustment (Default 7)

- **07** Adjustment of fast speed  
The higher the number the higher the voltage in the Fast Speed (Max 10, Min 3)

**dn** Motor Test (operate gates manually)

- **o1** Open M1  
Hold SET to Operate
- **c1** Close M1  
Hold SET to Operate
- **o2** Open M2  
Hold SET to Operate
- **c2** Close M2  
Hold SET to Operate

**EH** Exit the menu



## Manual Adjustment of Motor Working Time Menu (fine tuning of times)

- **L1** Total Working Time of M1 (OPENING)
- **S1** Starting Time of Slowdown for M1 (OPENING)
- **S2** Total Working Time of M2 (OPENING)
- **S2** Starting Time of Slowdown for M2 (OPENING)
- **L3** Total Working Time of M1 (CLOSING)
- **S3** Starting Time of Slowdown for M1 (CLOSING)
- **L4** Total Working Time of M2 (CLOSING)
- **S4** Starting Time of Slowdown for M2 (CLOSING)
- **d0** Opening Delay between M2 and M1 (Default 02)
- **d0** Closing Delay between M1 and M2 (Default 03)
- **Ll** Automatic Lock Relay Operation Time (Default 02)
- **Lp** Pedestrian Feature Operating Time (Default 05)



## Single Gate Mode (Default Double Gate)

- **Y5** Single Gate Mode
- **nt** Double Gate Mode



## Factory Default the Settings

- **Y5** Restore to Factory Default (Wireless memory is not affected)
- **nt** Cancel without change

**rc** Release Torque at the End of Travel (Default nt)

- **ys** Release end of travel torque (motors without Limit Switches ONLY)  
Reverses 0.5 seconds in the opposite direction after reaching the full open/closed position
- **nt** Does not release the torque at the end of travel

**cs** Kickback Stroke (Default nt)

- **ys** Provides a full speed jolt (0.5s) at the end of closing to aid in the latching of an electric lock, motors with limit switches only
- **nt** Feature is disabled

**ss** Soft Start

- **ys** Instead of starting motor(s) at full speed the operation begins at a reduced speed then ramps to full speed
- **nt** Feature is disabled

**sl** Limit Switches in SERIES to Motor (Default nt)

- **ys** Must be enabled when using a motor WITH limit switches and they are wired through the motor, i.e only a total of TWO wires directly back to the control board
- **nt** Feature is disabled, Used for over current motors OR motors requiring the Limit Switches wired DIRECTLY to the controller

**rn** Receiver Mode (1 Button/4 Button Receiver Mode) (Default 1b)

- **1b** One Button Mode for Open-Stop Close and Another Button for Pedestrian Open-Stop-Close  
STRONGLY RECOMENDED
- **4b** Four Button Layout

**ln** Automatic Lock Mode

- **ys** Magnetic Lock Mode (Magnetic Bar)  
Power OFF to Unlock
- **nt** Electric Lock Mode (Solenoid Lock)  
Power ON to Unlock
- **bo** Electric Bolt Mode (Solenoid Bolt)  
Power ON except when open/closed

**LS** Direct to control board Limit Switches (NOT in series to motor)

- **nc** Sets the controller to accept NORMALLY CLOSED limit switches directly to the control board limit switch terminals  
Opening  $E_o$  AND Closing edge  $E_c$  inputs must be set to **ds**
- **no** Sets the controller to accept NORMALLY OPEN limit switches directly to the control board limit switch terminals  
Opening  $E_o$  AND Closing edge  $E_c$  inputs must be set to **ds**

**E<sub>o</sub>** Opening Safety Edge Input (Default ds)

- **ds** Disabled
- **nc** Normally Closed Circuit  
Direct Limit Switch Mode **LS** CANNOT be used in this instance as the terminals are reserved for an edge sensor
- **no** Normally Open Circuit  
Direct Limit Switch Mode **LS** CANNOT be used in this instance as the terminals are reserved for an edge sensor
- **An** Analogue Edge with 8K2 Resistance  
Direct Limit Switch Mode **LS** CANNOT be used in this instance as the terminals are reserved for an edge sensor

**E<sub>c</sub>** Closing Safety Edge Input (Default ds)

- **ds** Disabled
- **nc** Normally Closed Circuit  
Direct Limit Switch Mode CANNOT be used in this instance as the terminals are reserved for an edge sensor
- **no** Normally Open Circuit  
Direct Limit Switch Mode CANNOT be used in this instance as the terminals are reserved for an edge sensor
- **An** Analogue Edge with 8K2 Resistance  
Direct Limit Switch Mode CANNOT be used in this instance as the terminals are reserved for an edge sensor

**P<sub>c</sub>** Photocell Input

- **nc** Sets the controller to accept NORMALLY CLOSED photocell
- **no** Sets the controller to accept NORMALLY OPEN photocell OR NO PHOTOCCELL CONNECTED

**SP** STOP Button Input

- **nc** Sets the controller to accept NORMALLY CLOSED Stop Button
- **no** Sets the controller to accept NORMALLY OPEN Stop Button OR NO STOP Button CONNECTED

**SF**

Special Detector Input (Default dt)

**PS**

Photostop Mode (Normally Closed Circuit)

Similar to a typical photocell input but also incorporates the opening cycle.

1. During opening it will pause gate till clear
2. During auto close it will restart the timer
3. During close it will stop the gates and re-open
4. Whilst closed it will inhibit the operation of opening until clear again

**dt**

Detector Mode (Normally Open Circuit) OR NO SENSOR CONNECTED

Used to signal the system that the gate has been used and is ready to close.

1. If detected whilst opening it will finish the opening then IMMEDIATELY close
2. Whilst closing it will re-open gate then IMMEDIATELY close the gate
3. Whilst open it will tell the gate to close

**BL**

Warning Light Mode

**YS**

Flashing illumination ON/OFF during the cycle

**nt**

Static illumination during the cycle

**So**

Full-time Photocell Check / Only Vitals (Solar Mode)

**Turns the Light output to a LPW Photocell Voltage Source**

**YS**

Check photocell Inputs before beginning and during the close cycle. N/C Logics Only

**nt**

Check photocell Input at all times including standby. N/C and N/O Logics

**AP**

Mobile APP Privileges (Module TSL1 Required)

**00**


User can only operate gate and check status

**01**


User has 00 Functions along with ability to change operating logics and change automatic closing time.

# Remote Learning/Wireless Button Learning

## C1 Command Learning



## C2 Command Learning



### Operating Logic



### Residential



### Commercial & Industrial



### Remote Channels




OPEN /STOP/ CLOSE	<u>Ped.</u> OPEN /STOP/ CLOSE
-------------------	-------------------------------


OPEN	CLOSE
------	-------

OPEN	PED. Open
------	-----------


## Delete by remote button



## Delete by enrollment number




## Delete entire memory




## Remote Usage

- A** Operate this Gate Open - Stop - Close (Programmed to C1)  
(also stops the automatic closing timer if pressed during the countdown)
- B** Operate Pedestrian Open - Stop - Close (Programmed to C2)  
(also stops the automatic closing timer if pressed during the countdown)
- C** Operate a garage door
- D** Operate another Gate Open - Stop - Close  
(also stops the automatic closing timer if pressed during the countdown)




**STX4K**  
Maximum Clear Line  
of Sight 100 Metres  
Operating Distance



**STX4L**  
Maximum Clear Line  
of Sight 800 Metres  
Operating Distance

## Identify the enrollment Number

From the standby Screen press each button on the remote INDIVIDUALLY, the number displayed on the screen upon each button press is the enrollment number, one remote MAY have multiple enrollment numbers based on the paired features



## Wireless Keypad Learning

The easiest way to pair a keypad is to take it to the gate controller BEFORE installing onto the post or fence. The installation steps below detail the procedure using the default codes. It is suggested to change the codes AFTER completing the procedure and testing using the default code.

Default code 1111= Channel 1 of Keypad, Default code 2222= Channel 2 of Keypad


### Operation Command Learning



### Pedestrian Gate




# Setting the Automatic Close Timer



-  **Photocell must be used to assist accident prevention. Not installing photocells is a safety risk.**
-  Pedestrian function will also inherit the automatic closing time. Consider the suitability and danger aspect for the installation.

# Optional TSL1 Mobile APP Expansion Module

Ensure the system is powered OFF before connecting in the TSL1 Mobile APP Module, reference the TSL1 APP module manual for Wi-Fi connection and mobile app usage.



# Motor Test Mode

The purpose of motor testing is to identify the correct operating procedure before the time travel calibration. The information that can be gained from the motor test is if the motors are wired:


- Correct polarity meaning they operate in the correct direction according to the control board.
- The limit switches have been correctly set for the OPEN and CLOSED position. This test can be repeated an unlimited amount until all is set correctly.
- The correct operating sequence FOR DOUBLE GATES

O2 will open Gate 2 (M2) - The MASTER gate with the AUTOMATIC LOCK if used, First gate to open/ONLY GATE IF SINGLE GATE  
 C2 will close Gate 2 (M2) - Second gate to close IF double gates/ONLY GATE

O1 will open Gate 1 (M1) - Second gate (SLAVE) to open IF double gates  
 C1 will close Gate 1 (M1) - First gate to close IF double gates

O1/C1 is not used for single gate systems

**NOTE: Safety Inputs are disabled during this stage**



## Troubleshooting MP

If the gate(s) close whilst using the open feature this is easily resolved and must be rectified prior to moving forward.

- Confirm which of the gate motor(s) is operating in the wrong direction
- Power down the controller
- Reverse the wires in the IDENTIFIED motor output terminal (this is the wires going to the gate motor)

## Troubleshooting LS

If the gate(s) travel past the desired stop point OR stops too early the limit switch is misconfigured and will need to be adjusted.

- Confirm which of the limit switches is not set correctly (open limit/close limit)
- Adjust the relevant limit cam/slider (refer to your gate motors installation manual)
- In cases of a direct wired limit switch ensure the appropriate motor terminal and open/close terminal is used

## Troubleshooting WM

In the case of double gates IF the gate that should open second is opening on O1 this must be rectified prior to moving forward.



- Power down the controller
- SWAP the wires in M1 terminal to M2 and the wires in M2 to the M1 terminal

# Learn Time Calibration for Double Gate

The automatic learning procedure will teach the gate controller the operational times for the gate motors travel, this will allow for the correct calibration and introduce a slowdown at the appropriate position along with the relevant protection cut off time.


**Please ensure that the motors testing procedure has been completed successfully before following the below procedure (page 19 of Premier SW24T Manual).**

**NOTE: Safety Inputs are disabled during this stage**



**8** M1 will close followed by M2 til they reaches the limit or stop *t1* will be displayed during the operation of M1. There will be a delay between the two motor operations ( *dc* Delay time) .

**9** M2 will open followed by M1 til they reaches the limit or stop *t4* will be displayed during the operation of M1. There will be a delay between the two motor operations ( *do* Delay time) .






# Learn Time Calibration for Single Gate

The automatic learning procedure will teach the gate controller the operational times for the gate motors travel, this will allow for the correct calibration and introduce a slowdown at the appropriate position along with the relevant protection cut off time.

**Please ensure that the motors testing procedure has been completed successfully before following the below procedure (page 19 of Premier SW24T Manual).**

**NOTE: Safety Inputs are disabled during this stage**



## Advanced Manual Learn Time Calibration for Double Gate

The advanced manual learning procedure is used when the gates are unable to learn correctly during the automatic learning phase, it is a higher detail operation as the installer provides input on the gate slow down (DECEL) and Stop Positions (when no limits are used) .

**Please ensure that the motors testing procedure has been completed successfully before following the below procedure (page 19).  
Please ensure that the system is set to DOUBLE GATE mode before proceeding (page 12).**

**Please ensure gates are closed prior to proceeding**

**NOTE: Safety Inputs are disabled during this stage**



A. Both gates begin to open in a slow speed (you can fine tune the slow speed trimmer to increase/decrease the speed whilst observing the operation), once both gates are OPEN press OK

B. Press OK to begin the closing phase of the learning, M1 will begin to close

C. Press OK again to command M2 to begin closing

D. Press OK again to set the slowdown position of M1

E. Press OK again to set the slowdown position of M2

If limit switches are installed AND set correctly the controller will detect the closed point and automatically finish the manual learning.

If no limit switches are used OR limits are not set correctly:

F. Press OK to stop M1 in the closed position

G. Press OK to stop M2 in the closed position

## Advanced Manual Learn Time Calibration for Single Gate

The advanced manual learning procedure is used when the gate is unable to learn correctly during the automatic learning phase, it is a higher detail operation as the installer provides input on the gate slow down (DECEL) and Stop Positions (when no limits are used) .

**Please ensure that the motors testing procedure has been completed successfully before following the below procedure (page 19).  
Please ensure that the system is set to SINGLE GATE mode before proceeding (page 12).**

**Please ensure gates are closed prior to proceeding**

**NOTE: Safety Inputs are disabled during this stage**



A. The gate begin to open in a slow speed (you can fine tune the slow speed trimmer to increase/decrease the speed whilst observing the operation), once the gate is OPEN press OK

B. Press OK to begin the closing phase of the learning, M2 will begin to close

C. Press OK again to set the slowdown position of M2

If limit switches are installed AND set correctly the controller will detect the closed point and automatically finish the manual learning.

If no limit switches are used OR limits are not set correctly:

D. Press OK to stop M2 in the closed position

# Photocells


## Typical Photocell Arangement

SEE NEXT PAGE ON SPECIAL DETECTOR AND PHOTOSTOP


Photocells are a necessity when automating, they provide an additional layer of safety by infrared beam across the driveway.

The photocell terminal is used as the primary photocell connection which will revert the gate back to open when an obstacle is detected during close. If an obstacle is present before a close command then it will prevent closure til the obstacle is clear.


In the case where the automatic closing timer is used then each time an obstacle passes through the photocell infrared beam the timer will restart.



## Powered Systems



## Solar Systems (Must use NC Logic)



Full-time Photocell Check / Only Vitals (Solar Mode)

**Turns the Light output to a LPW Photocell Voltage Source**



Check photocell Inputs before beginning and during the close cycle. N/C Logics Only



## Troubleshooting PC



If after powering the system on you receive the error PC displayed it means one of the following:

1. Bad photocell alignment or there is an obstacle, wave your hand in front of the RECEIVER photocell, you should hear a very low audibility click, this means the photocell is in alignment. No click means bad alignment, incorrect/bad wiring or no power at one or both each cells- check there LED indicators.
2. Wired/set for wrong relay on photocell, if totally covering the photocell the error disappears on the display It means the wiring/selection jumper on the RECEIVER photocell is incorrect OR the incorrect setting within the photocell menu has been chosen.

An additional set of photocells installed just past the gates open position. Ideal for scenarios requiring a command to close after the vehicle has passed through OR carport safety, outwards opening gate open prevention, etc.



Photostop Mode (Normally Closed Circuit)



Similar to a typical photocell input but also incorporates the opening cycle.

1. During opening it will pause gate till clear
2. During auto close it will restart the timer
3. During close it will stop the gates and re-open
4. Whilst closed it will inhibit the operation of opening until clear again



Detector Mode (Normally Open Circuit) OR NO SENSOR CONNECTED



Used to signal the system that the gate has been used and is ready to close.

1. If detected whilst opening it will finish the opening then after two seconds close
2. Whilst closing it will re-open gate then after two seconds close the gate
3. Whilst open it will tell the gate to close

Troubleshooting PS/DT

If after powering the system on you receive the error PS or dt displayed it means one of the following:




1. Bad photocell alignment or there is an obstacle, wave your hand in front of the RECEIVER photocell, you should hear a very low audibility click, this means the photocell is in alignment. No click means bad alignment, incorrect/bad wiring or no power at one or both each cells- check there LED indicators.



2. Wired/set for wrong relay on photocell, if totally covering the photocell the error disappears on the display It means the wiring/selection jumper on the RECEIVER photocell is incorrect OR the incorrect setting within the special detector menu has been chosen.

## Automatic Electric Lock (Fortress-EL)


The Fortress EL automatic electric lock will engage mechanically when closed into the latching plate and automatically release on the opening cycle. It provides added security and holding characteristics to prevent forces from pushing against the gate(s).



## FORTRESS ML Magnetic Lock (EML-280)


NOT SUITABLE FOR SOLAR

The FORTRESS ML automatic magnetic lock will engage electrically when closed against by magnetizing to the armature plate and automatically release on the opening cycle. Just like an electric lock it also provides added security and holding characteristics to prevent forces from pushing against the gate(s). Benefit of a magnetic lock is that it can be mounted in different methods to the electric locks traditional mounting arrangements.




## Fortress Automatic Electric Bolt (Fortress-EB)

The Fortress automatic electric bolt is powered in both the opening and closing directions to ensure the bolt is retracted before leaving the plunger engagement point and also before arriving to the engagement point.




## Wi-Fi APP Switch (Tekno-WF)

The Tekno Wi-Fi App Switch integrates into the system allowing for operation by APP anywhere in the world, the Tekno module requires good 2.4GHZ connection to the Wi-Fi of the premises.



## Loop Detector (Loop12V)

Typically for commercial and industrial use the loop detector can be used to command an OPEN or a CLOSE operation when detecting a vehicle.




Only Used with Logic Modes "Typical Complex", "Typical Complex with Automatic Closing Timer" or "Secure Complex"


## Digital Weekly Timer (WT-12V)

Typically for commercial and industrial the gate can be set to open at a certain time (and hold open), then close also at a set time. Multiple times can be programmed for all 7 days of the week selectively.

All other operations (outside of weekly time, eg. After Hours) by other access control devices such as a keypad will result in an automatic closing after the set control board automatic closing timer.




A Tekno K1 wired keypad is typically (but not exclusively) used in a commercial or industrial environment as a wireless keypad can be used in a residential home. A wired keypad has little to no maintenance required as its power feed is supplied by the system through wiring.




## E Loop (WDT)

A wireless vehicle detector installed in commercial driveways or longer residential driveways to toggle the automatic opening of the gate.




## Warning Light Output (24V)




## 4G Module (Tekno S1)

The Tekno S1 uses a sim card to allow authorized users to operate the gate by a phone call from anywhere in the world.




## Push Button (WPB-PRESS/WPB-MHEAD)

Suitable for all applications a push button can be used to operate the gate simply by pressing the button.




## Emergency Stop Button (WPB-STOP)

An emergency stop button is used typically if the system is in a manned operation such as a security office or gate house OR such applications where an internal door is automated.



## ANT-5DB Antenna

The Antenna will assist with remote signal in a case where the signal has been blocked by the fencing or the gate. The antenna should be installed as high as possible allowing it to be visually seen over the fence line.



Remote Enrollment number	Users Name/Employee ID	Feature
01		
02		
03		
04		
05		
06		
07		
08		
09		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		

## Warranty Terms and Conditions

The product is warranted for a period of twelve months (one year) from the date of purchase, unless expressly specified as extended warranty (extension to the warranty period). The product is to be installed for its intended purpose and for normal use as outlined within the installation manual, the product warranty is exclusively for defects in manufacturing and manufacturing workmanship. It does not cover out of guidelines use, natural or other disasters, abnormal weather conditions, damage incurred in shipping or handling, damage caused by disaster such as fire, flood, wind, earthquake, lightning, excessive voltage, mechanical shock, water damage, damage caused by unauthorized attachment, alterations, modifications, or foreign objects, damage caused by peripherals (unless such peripherals were supplied by Automation Systems Australia), defects caused by failure to provide a suitable installation environment for the products, damage caused by usage of the products for purpose other than those for which it was designed, damage from improper maintenance, damage arising out of any other abuse, mishandling, and improper application of the products.

At its discretion Automation Systems Australia will require the item determined by the support staff to be returned to base in its original unmodified condition for a warranty inspection if within the warranty period. A return authorization "RA" number will be provided to be enclosed with the product in question. The warranty will not cover freight fees to base, customs fees or any labour costs at the installation site but will cover repair or replacement of the product as seen fit. Automation Systems Australia will cover the freight of the returned item to the original address if deemed as a warranty repair or replacement item. Any warranty repairs or replacements continue to carry through the remaining warranty period and do not extend or restart the period.

Under no circumstances shall Automation Systems Australia be liable for any special, incidental, or consequential damages based upon breach of warranty, breach of contract, negligence, strict liability, or any other legal theory. Such damages include, loss of profits, loss of the product or any associated equipment, cost of capital, cost of substitute or replacement equipment, facilities or services, down time, purchaser's time, the claims of third parties, including customers, and injury to property.

This warranty contains the entire warranty and shall be in lieu of any and all other warranties, whether expressed or implied (including all implied warranties of merchantability or fitness for a particular purpose). And of all other obligations or purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning this product.

Automation Systems Australia will at its option repair or replace out-of-warranty products at a determined cost which are returned to its base according to the following conditions. Anyone returning goods to Automation Systems Australia must first obtain an authorization number. Automation Systems Australia will not accept any shipment whatsoever for which prior authorization has not been obtained. Products which Automation Systems Australia determines to be repairable will be repaired and returned. A set fee which Automation Systems Australia has been predetermined and which may be revised from time to time will be charged for each unit repaired. Products which Automation Systems Australia determines not repairable will be replaced by the nearest equivalent product available at that time. The current market price for the replacement product will be charged for each replacement unit.