



Automation Systems®
AUSTRALIA

TITAN 2410

with SL24T Advanced
Digital Sliding Gate Controller



Tuya Smart
Compatible



Step by Step Simple
Installation
Guide on Page 2



**Photocell must be used to assist accident prevention.
Not installing photocells is a safety risk.**

Control Board
Designed & Engineered




In Italy


Table of Contents

1	Specifications, Dimension and Tools Required
2	Step By Step Installation Guide
3	Installation Layout/Wiring Layout
4	Motor Installation
5	Motor Installation Continued
6	Controller Layout and Display Screen Status
7	CERO / Cero M10 Standalone Solar System Connection
8	Battery Backup Connection, Power Transformer Connection
9	DECEL, TIME and OBSTF Trim pot Adjustments, System Menu Hierarchy
10	Basic Menu (operating logic)
11	Basic Menu continued (wireless learning, automatic closing time, working time learning, fast speed level and Motor Test)
12	Core Menu (manual time adjustments, gate direction, photocell, stop, limit switch polarity)
13	Core Menu continued (special detector, soft start, opening edge, closing edge, manned depot mode)
14	Core Menu continued (warning light, solar mode, mobile app privileges)
15	Remote and Wireless Button Learning (detailed)
16	Remote Deleting (detailed), Remote Usage
17	Enrolment, Wireless Keypad Learning (detailed), Automatic Closing Timer
18	Optional TSL1 Mobile App Module Connection , Motor Test
19	Learn Time Calibration/Gate Calibration
20	Photocells
21	Special Detector/Secondary Photocells
22	Tekno Wi-Fi Switch, Tekno S1 4G Module, Tekno K1 Keypad
23	E Loop, Loop Detector, Digital Weekly Timer
24	Warning Light, Push Button, Emergency stop button, Antenna
25	Fill In Enrolment List
26	Warranty Terms


Typical Tools Required




2/2.5mm Flat Head for Terminal Connections




Socket & Spanner Sets



Multi Meter (not essential)




Wire Stripper



Drill and Drill Bits Masonry and Metal


Specifications

Operating Voltage	24V DC
Standby Consumption	~40mA
Battery Backup	Yes (Optional)
Speed	22-36 CM/S
Motor Limit	N/C Micro Switch
Torque	27 NM
Duty Cycle	40%
Warning Light Output	24VDC 1A MAX
Accessories Power	12V DC (250mA)
Safety Inputs	Photocell, Detector, Safety Edge
Operation Temperature	-10°C to +60°C
Remote Button Capacity	250




*Tested ratings are level gate installations and does not take into account inclined installations


Dimensions



Step by Step Installation Guide



Manual Release




To manually release (disengage clutch):

1. Slide the key cover UP
 2. Insert the key (fits only one way into the cylinder) and turn the key clockwise.
 3. Turn the lever one full turn clockwise (360°)
- Gate can now be moved by hand.

To return to automated mode (engage clutch):

1. Turn the lever one full turn counter-clockwise (360°)
 2. Insert the key (fits only one way into the cylinder) and turn the key counter-clockwise.
 3. Slide the key cover DOWN
- Gate cannot be moved by hand and is ready for automated use.

Installation Layout



Number	Accessory	Requirements
A	Gate Motor	Power by transformer or Solar
C	Entry Keypad	Dex 4 (wireless), All others wired to gate controller by 4 core cable
D	Exit Keypad	Dex 4 (wireless), All others wired to gate controller by 4 core cable
E	Gate Stop	Physically Mounted Hardware Item. Mandatory Stop to prevent accident or injury incase of failure
F	Induction Loop/E Loop	Housed inside gate controller with 1 core cable for the driveway loop. E Loop: E trans Housed inside controller. Wireless to E Loop
G	PhotoCell Transmitter	No cable required for Dukie XR (Reflector) or Battery TX, Dukie X 2 core Cable to gate controller
H	PhotoCell Receiver	4 Core cable to gate controller
I	Gate Controller Power Source	Mains, Outdoor Transformer or Solar Battery System to the Gate Controller
J	Meeting Point	Physically Mounted Hardware Item
K	Gate Top Guide	Physically Mounted Hardware Item
L	Ground Track	Physically Mounted Hardware Item
M	ADDITIONAL PhotoCell Transmitter	Optional Additional Safety Device, No cable required for Dukie XR (Reflector) or battery TX, Dukie X 2 core Cable to gate controller
N	ADDITIONAL PhotoCell Receiver	Optional Additional Safety Device, 4 Core cable to gate controller
O	Warning Light	2 core cable to gate controller

Motor Installation

Step 1

Identify the OPENING direction of your gate based on the illustrations below.

Gate opens to the LEFT or RIGHT is always made from the inside looking towards the street (outside).





Step 2



Mark the centre of the mounting holes of the base plate, note the orientation of the large conduit entry hole.


The base plate should be positioned 50mm from the support post/edge of the driveway.

The base plate is positioned 50mm away from the backside of the gate to achieve the correct base distance for the limit switch spring and gear rack alignment. The motor distance can be fine tuned when installing to the base plate.



Step 3

Drill the four fixing hole using a 10mm masonry drill, ensure that the holes are cleaned thoroughly in preparation to install the dyna bolts. Install the base plate ensuring it is stable.



Step 4

Install the gate motor to the metal base plate, ensure the front of the plate (side facing the gate) is flush with the front of the gate motor.



Step 5

Manually Release the gate motor and set the gate 250mm from the open position .


Sit a piece of gear rack on top of the motors pinion gear and level it according to the gates current level (adjustable later), allow for a 2-3mm clearance (backlash) between the top of the pinion tooth and the base of the gear rack.

Screw in the first piece of gear rack in place using self drilling metal screws in the CENTRE of the elongated hole.


Slide in the next adjoining piece of gear rack and close the gate by hand til the pinion is centred to the ne piece of gear rack that has been added, once again as per the previous step the rack should be levelled according to the gates current level (adjustable later), once again allow for a 2-3mm clearance (backlash) between the top of the pinion tooth and the base of the gear rack.

Screw the piece of gear rack in place using self drilling metal screws in the CENTRE of the elongated hole.


Repeat this step until the gate has gear rack installed across its entire length.



2-3 mm space between the
Top of Pinion Tooth
and the gear rack root



Approx.
100mm
Base of gear
rack
to concrete



Step 6

Manually open and close the gate at a very slow speed, observe that the gear rack always retains the 2-3mm clearance backlash.

If the gate feels tight in certain areas most likely the backlash is less than advised, loosen the gear rack piece and adjust to correct then re-test.

If the gate feels loose in certain areas or the rack slips off the pinion most likely the backlash is greater than advised, loosen the gear rack piece and adjust to correct then re-test.

Step 7




Install the TWO bolts to each striker plate.

OPEN the gate til 50mm before it touches the gate stop.


Install the striker plate to the gear rack THE SPRING SHOULD BE BENT to 45°, the striker plate CLAMPS to the gear rack and does not require any holes to be drilled.

CLOSE the gate til 20mm before it touches the meeting points base.

Install the striker plate to the gear rack THE SPRING SHOULD BE BENT to 45°, the striker plate CLAMPS to the gear rack and does not require any holes to be drilled.



Gate has travelled to the left and has engaged the spring to a 45° bend



Gate has travelled to the right and has engaged the spring to a 45° bend


Step 8

Cut off any EXCESS gear rack using an angle grinder, ensure the motor cover is installed and the excess rack is in the furthest possible and safe position away from the motor, cutting will produce sparks due to the racks steel core, ensure no stray sparks reach the gate motor to avoid damage.

Slip on the side covers on each side to cover the mounting bolts.

Move the gate to the half way point and engage the clutch and proceed to Motor Testing (pg18) followed by learn time calibration (pg19)

Controller Layout



- 16. LPW + (Photocell Power in Solar Mode)
- 17. LPW - (Photocell Power in Solar Mode)
- 18. Light Output + (Not Regulated)
- 19. Light Output -

Display Screen Status

General

- Standby
- oP Opening
Fast Speed 0.5 Second Flash
Slow Speed 1 Second Flash
- cL Closing
Fast Speed 0.5 Second Flash
Slow Speed 1 Second Flash
- Fo Full Open Position
- Fc Full Close Position
- . Battery Backup Mode/Low input Power (Flashes)
- 99 Automatic Closing Timer

Safety Status

- Pc Photocell Input Active
- SP STOP Input Active
- PS Photostop Input Active (Special Detector)
- dt Detector Input Active (Special Detector)
- Eo Edge Input Active (Opening Edge)
- Ec Edge Input Active (Closing Edge)

Operating Input Status

- St Start Input Active
Operating Logic: St Rt
- Pd Pedestrian Input Active
Operating Logic: St Rt
- oP Open Input Active
Operating Logic: oc oA cd
- cL Close Input Active
Operating Logic: oc oA cd

CERO/CERO M10 Standalone Solar System Connection


A standalone solar system is a totally off grid solution used for green energy initiatives or simply when its not possible to run power to the gate system. To conserve power constant power draw devices such as wired keypads are not to be used. The alternatives are wireless keypads (use there own batteries).




ALWAYS Connect the Solar Panel AFTER the batteries to ensure the system can Auto-Detect the voltage configuration.

Batteries Connections


Step 1: Connect the Batteries First



Step 2: Connect the Solar Panel Second



Step 3: Connect the Load/Control board Output Last



CERO M10 "▲" Turns ON/OFF the Output
CERO "SET" button Turns ON/OFF the Output

Charge controller output is OFF and terminal block is unplugged for wiring works.



INPUT Terminal
Positive on RIGHT SIDE (+)
Negative on LEFT SIDE (-)


Battery Backup Connection

The battery backup will allow for uninterrupted usage in case of a power disruption. The battery backup system can operate the gate for a period of 4-6 hours during the power disruption. Once the power is restored the system will automatically recharge the battery system ready for the next use.




Multi Output Toroidal Transformer (Internal)

The transformer on a mains powered system is the primary source of power, it takes the high voltage input and transforms to low voltage which is connected to the controller. By default the controller uses the lower of the two outputs (white wire) which is typically suggested for most gate installs however incase required due to environmental forces it would be suggested to swap the lower output (green wire) for the higher output (yellow wire).



Outdoor Low Voltage Weatherproof Transformer (OT-24)

Where a power point is not available at the gate the Outdoor Transformer is used as the primary source of power, it takes the high voltage input and transforms to low voltage which is connected to the controller through the low voltage extension cable for a maximum distance of 100 metres.




"DECEL" Slow Speed/De-acceleration Adjustment



DECEL

The "DECEL" Trim pot is the slow speed trimmer allowing a fine tuning of the SLOW Speed portion of the operating cycle, Typically adjustment range is 20% to 50% from the slowest speed (minimum) depending on gate size, weight and inertia.




"TIME" Slow Down Position Adjustment



TIME

The "TIME" Trim pot is the adjustment in where the controller introduces the slow down speed. A TOO late position may cause the gate to stop more abruptly as it has not had enough time to decrease the speed of movement.

A TOO early position may cause difficulties in overcoming resistance points within the sliding movement of the gate and also creates a slower operating cycle time which may be undesirable.




"OBST.F" Obstruction/Overcurrent Adjustment



OBST.F


The "OBST.F" Trim pot is the pressure sensing adjustment before the controller recognises cut-off. Gate and Environmental factors will determine how high or low to adjust based on gate weight and the required power to operate the motor.

Setting too high will affect how quickly the controller will shut off under load or accident. setting too low can cause the controller to shut off too early (too sensitive) and cause intermittent operations.



System Menu Hierarchy

Throughout the manual to simplify identification the two preliminary menus will be displayed with a coloured background as illustrated below, any sub-menus and exit will be displayed with a grey background.



EXIT will take you back one level

From preliminary menus it will return to standby

From any setting menu it will cancel the change and return you to the preliminary menu



If in a setting adjustment and you wish to cancel press UP and DOWN together momentarily to return back one level.



If in a preliminary menu it will function the same as scrolling to exit.



Setting the system Operating Logic (Default Standard)

- 
Standard
 Operates OPEN/CLOSE by remote and/or wired-wireless accessories
- 
Standard WITH Automatic Closing Timer [Adjust the Automatic Closing Timer in 5P menu](#)
 Operates OPEN remote and/or Wireless Accessories with an automatic closing timer (can still be closed earlier by remote and/or wired-wireless accessories)
 Timer can be cancelled using the STOP feature
- 
Typical Complex
 Operates OPEN/CLOSE by remote and/or wired-wireless accessories with the WIRED input terminals switching to loop detector mode OPEN Terminal and CLOSE Terminal
- 
Typical Complex WITH Automatic Closing Timer [Adjust the Automatic Closing Timer in 5P menu](#)
 Operates OPEN/CLOSE by remote and/or wired-wireless accessories with the WIRED input terminals switching to loop detector mode OPEN Terminal and CLOSE Terminal along with an automatic closing timer (can still be closed earlier by remote and/or wired-wireless accessories)
 Timer can be cancelled using the STOP feature
- 
Secure Complex Mode WITH Automatic Closing [Adjust the Automatic Closing Timer in 5P menu](#)
 Ignores additional commands during opening, automatic closing by the adjustable timer ONLY, no other methods to close

Wired Input Terminals		Operating Logic	Remote Channels		
Terminal 3 (ST/OP)	Terminal 4 (PD/CL)				
OPEN /STOP/ CLOSE	<u>Ped.</u> OPEN /STOP/ CLOSE		OPEN /STOP/ CLOSE	<u>Ped.</u> OPEN /STOP/ CLOSE	Stop/Cancel Automatic Closing Timer
OPEN	CLOSE		OPEN	CLOSE	Stop
OPEN	CLOSE		OPEN	CLOSE	Stop/Cancel Automatic Closing Timer
OPEN	N/A		OPEN	N/A	Cancel Automatic Closing Timer

"OPEN" only commands always restart an automatic closing timer (if applicable).
 any "STOP" command by remote control always cancels the automatic closing timer (if applicable).
 any "CLOSE" command will bypass the automatic closing timer (if applicable) and close the gate.

Lc Remote and Wireless Keypad Learning/Deleting
Detailed Page 15, 16 & 17,

- **c1** C1 Command
- **c2** C2 Command
- **c4** STOP Command Learning
- **rt** Delete WITH the wireless component present
- **rn** Delete by memory position
- **rb** Delete the entire memory (format)

Lt Learn Working Times → Starts the learning procedure

SP Automatic Closing Time (Default 10 seconds)

- **99** Only valid when using an OPERATION LOGIC **oL** that uses automatic closing
01= Immediate Close
2-299= Delayed automatic Closing Time by the set value in Seconds

FS Fast Speed Level (Default 07) → **07** Sets the fast speed Percentage of input voltage (slow speed adjustment is by Trim Pot)
Re-Calibration after each change required
03= Minimum (30%)
10= Maximum (100%)


UP Motor Test (operate gate manually)

- **oP** Opens the gate
Hold MODE to Operate
- **cL** Closes the gate
Hold MODE to Operate

EH Exit the menu

Core Menu


tA Manual Adjustment of Working Time Menu (fine tuning of times)




Gd Gate Direction (Default Right Hand Opening)




Pc Photocell Input



SP STOP Button Input



LS Limit Switch Polarity



SF Special Detector Input (Default dt)

- **PS** Photostop Mode (Normally Closed Circuit)
 Similar to a typical photocell input but also incorporates the opening cycle.
 1. During opening it will pause gate till clear
 2. During auto close it will restart the timer
 3. During close it will stop the gates and re-open
 4. Whilst closed it will inhibit the operation of opening until clear again
- **dt** Detector Mode (Normally Open Circuit) OR NO SENSOR CONNECTED
 Used to signal the system that the gate has been used and is ready to close.
 1. If detected whilst opening it will finish the opening then IMMEDIATELY close
 2. Whilst closing it will re-open gate then IMMEDIATELY close the gate
 3. Whilst open it will tell the gate to close

Eo Opening Safety Edge Input (Default ds)

- **SP** Stop Button Input mode (set stop button N/O or N/C by the **SP** menu).
- **ds** Disabled
- **nc** Normally Closed Circuit
- **no** Normally Open Circuit
- **An** Analogue Edge with 8K2 Resistance

Ec Closing Safety Edge Input (Default ds)

- **ds** Disabled
- **nc** Normally Closed Circuit
- **no** Normally Open Circuit
- **An** Analogue Edge with 8K2 Resistance

SS Soft Start

- **ys** Instead of starting motor(s) at full speed the operation begins at a reduced speed then ramps to full speed
- **nt** Feature is disabled

6L

Light Output Mode

- **45** Flashing illumination ON/OFF during the cycle
- **nt** Static illumination during the cycle

d2

Factory Default the Settings

- **45** Restore to Factory Default (Wireless memory is not affected)
- **nt** Cancel without change

rA

Receiver Mode (1 Button/4 Button Receiver Mode) (Default 1b)

- **1b** One Button Mode for Open-Stop Close and Another Button for Pedestrian Open-Stop-Close
STRONGLY RECOMENDED
- **4b** Four Button Layout

5o

Full-time Photocell and Photostop Check / Only Vitals (Solar Mode)

- **45** Check photocell/photostop Inputs before beginning and during the cycles. N/C Logics Only
- **nt** Check photocell/Photostop Inputs at all times including standby. N/C and N/O Logics


AP

Mobile APP Privileges (Module TSL1 Required)


- **00** User can only operate gate and check status
- **01** User has 00 Functions along with ability to change operating logics and change automatic closing time.

Remote Learning

C1 Command Learning



C2 Command Learning



Operating Logic



Residential



Commercial & Industrial



Remote Channels




OPEN /STOP/ CLOSE	<u>Ped.</u> OPEN /STOP/ CLOSE
-------------------------	-------------------------------------

OPEN	CLOSE
------	-------


OPEN	N/A
------	-----

C4 Remote STOP command Learning




The display will also show you the enrolled position it has been stored in the memory, this can be noted incase you wish to delete a specific remote later.


Delete by remote button



Delete by enrollment number




Delete entire memory




Remote Usage

- A Operate this Gate Open - Stop - Close
(also stops the automatic closing timer if pressed during the countdown)
- B Operate Pedestrian Open - Stop - Close
(also stops the automatic closing timer if pressed during the countdown)
- C Operate a garage door, etc.
- D Operate another Gate Open - Stop - Close
(also stops the automatic closing timer if pressed during the countdown)




STX4K
Maximum Clear Line
of Sight 100 Metres
Operating Distance



STX4L
Maximum Clear Line
of Sight 800 Metres
Operating Distance

Identify the enrollment Number

From the standby Screen press each button on the remote INDIVIDUALLY, the number displayed on the screen upon each button press is the enrollment number, one remote MAY have multiple enrollment numbers based on the paired features




Wireless Keypad Learning


The easiest way to pair a keypad is to take it to the gate controller BEFORE installing onto the post or fence. The installation steps below detail the procedure using the default codes. It is suggested to change the codes AFTER completing the procedure and testing using the default code.

Default code 1111= Channel 1 of Keypad, Default code 2222= Channel 2 of Keypad


Operation Command Learning



Pedestrian Gate




Setting the Automatic Close Timer



Optional TSL1 Mobile APP Expansion Module

Ensure the system is powered OFF before connecting in the TSL1 Mobile APP Module, reference the TSL1 APP module manual for Wi-Fi connection and mobile app usage.




Motor Test Mode

The purpose of motor testing is to identify the correct operating procedure before the time travel calibration. The information that can be gained from the motor test is if the motors are wired:

- Correct polarity meaning they operate in the correct direction according to the control board.
- The limit switches have been correctly set for the OPEN and CLOSED position. This test can be repeated an unlimited amount til all is set correctly.

NOTE: Safety Inputs are disabled during this stage



Troubleshooting MP

If the gate(s) close whilst using the open feature this is easily resolved and must be rectified prior to moving forward.

- Return to Standby
- Go to the Advanced Menu
- go to *cd* Gate Direction Menu
- Select the appropriate Direction being *rh* for Right Hand Opening and *lh* for Left hand opening
- Restart the Motor testing procedure

Troubleshooting LS

If the gate(s) travel past the desired stop point OR stops too early the limit switch stiker is mis-configured and will need to be adjusted/set.

- Confirm which of the limit switch metal striker plates is not set correctly (open limit/close limit)
- Adjust /install the relevant limit switch striker.

Learn Time Calibration

The automatic learning procedure will teach the gate controller the operational times for the gate motors travel, this will allow for the correct calibration and introduce a slowdown at the appropriate position along with the relevant protection cut off time.

Please ensure that the system is set to the appropriate direction before proceeding (page 12).

Please ensure that the motors testing procedure has been completed successfully before following the below procedure (page 19).

NOTE: Safety Inputs are disabled during this stage

1  From the standby screen press the MODE button once

2  Cycle to *dn* and press MODE

3



Cycle to *c1* and HOLD set, whilst holding set it will CLOSE the gate and it will stop on the limit switch, release the MODE Button

4



Cycle to *EH* to return to previous menu

5



Cycle to *Lt* for automatic learning and press MODE


If during the *c1* stage the gate did not close completely return to the motor test page and see **Troubleshooting LS**

6 The gate will OPEN to the set open position at a fast speed and stop after engaging the open limit switch to the metal striker plate.

7 The gate will now CLOSE to the set closed position at a fast speed and stop after engaging the close limit switch to the metal striker plate.








Troubleshooting OBSTF

If AFTER the Automatic learning stage *Lt* the gate did not completely open or completely close BUT was successful during the learning phase from earlier then adjust the obstruction OBSTF potentiometer clockwise SLIGHTLY and re-test.

THIS ADJUSTMENT IS NOT USED DURING THE LEARNING

Adjust in small increments only until function correctly, do not adjust in large increments





Photocells / Reflective Sensors are a necessity when automating, they provide an additional layer of safety by infrared beam across the driveway.



The photocell terminal is used as the primary sensor connection which will revert the gate back to open when an obstacle is detected during close. If an obstacle is present before a close command then it will prevent closure til the obstacle is clear.

In the case where the automatic closing timer is used then each time an obstacle passes through the photocell infrared beam the timer will restart.

Powered Systems



Solar System (Must use NC Logic)



Troubleshooting PC



If after powering the system on you receive the error Pc displayed it means one of the following:



1. Bad photocell alignment or there is an obstacle, wave your hand in front of the RECEIVER photocell, you should hear a very low audibility click, this means the photocell is in alignment. No click means bad alignment, incorrect/bad wiring or no power at one or both each cells- check there LED indicators.
2. Wired/set for wrong relay on photocell, if totally covering the photocell the error disappears on the display It means the wiring/selection jumper on the RECEIVER photocell is incorrect OR the incorrect setting within the photocell menu has been chosen.
3. If a solar system (using LPW power output) set the controller So to Ys

If all above is OK, then bad photocell alignment, wiring problem or there is an obstacle.

For solar systems temporarily use the OUT + terminal to power the photocell (ensure the LPW+ terminal is disconnected), then wave your hand in front of the RECEIVER photocell, you should hear a very low audibility click, this means the photocell is in alignment. No click means bad alignment, incorrect/bad wiring or no power at one or both each cells- check there LED indicators.

An additional set of photocells installed just past the gates open position. Ideal for scenarios requiring a command to close after the vehicle has passed through and used to signal the system that the gate has been used and is ready to close.

1. If detected whilst opening it will finish the opening then IMMEDIATELY close
2. Whilst closing it will re-open gate then IMMEDIATELY close the gate
3. Whilst open it will tell the gate to close (Detector)



Photostop Mode (Normally Closed Circuit) Solar Compatible


Similar to a typical photocell input but also incorporates the opening cycle.

1. During opening it will pause gate till clear
2. During auto close it will restart the timer
3. During close it will stop the gates and re-open
4. Whilst closed it will inhibit the operation of opening until clear again

Detector Mode (Normally Open Circuit) OR NO SENSOR CONNECTED

Used to signal the system that the gate has been used and is ready to close.

1. If detected whilst opening it will finish the opening then after two seconds close
2. Whilst closing it will re-open gate then after two seconds close the gate
3. Whilst open it will tell the gate to close



Troubleshooting PS/DT

After powering the system the display may flash error *PS* or *dt*



1. If a solar system, only photostop can be used (using LPW power output) set the controller *S_o* to *Y_s*
2. Ensure the photocell receivers jumper is also set to the correct NO/NC Setting






If all above is OK, then bad photocell alignment, wiring problem or there is an obstacle.

For solar systems temporarily use the OUT + terminal to power the photocell (ensure the LPW+ terminal is disconnected), then wave your hand in front of the RECEIVER photocell, you should hear a very low audibility click, this means the photocell is in alignment. No click means bad alignment, incorrect/bad wiring or no power at one or both each cells- check there LED indicators.




Tekno Wi-Fi APP Switch

The Tekno Wi-Fi App Switch integrates into the system allowing for operation by APP anywhere in the world, the Tekno module requires good 2.4GHZ connection to the Wi-Fi of the premises.



4G Module (Tekno S1)




The Tekno S1 uses a sim card to allow authorized users to operate the gate by a phone call from anywhere in the world.



Tekno K1 Wired Keypad

NOT SUITABLE FOR SOLAR

A Tekno K1 wired keypad is typically (but not exclusively) used in a commercial or industrial environment as a wireless keypad can be used in a residential home. A wired keypad has little to no maintenance required as its power feed is supplied by the system through wiring.





E Loop (WDT)

A wireless vehicle detector installed in commercial driveways or longer residential driveways to toggle the automatic opening of the gate.



Only Used with Logic Mode "Secure Complex"





Loop Detector (12 Volt Version)

Typically for commercial and industrial use the loop detector can be used to command an OPEN or a CLOSE operation when detecting a vehicle.



Only Used with Logic Mode "Secure Complex"





Digital Weekly Timer (12 Volt Version)

Typically for commercial and industrial the gate can be set to open at a certain time (and hold open), then close also at a set time. Multiple times can be programmed for all 7 days of the week selectively.




All other operations (outside of weekly time, eg. After Hours) by other access control devices such as a keypad will result in an automatic closing after the set control board automatic closing timer.



Only Used with Logic Mode "Secure Complex"






Warning Light Output (24V)



THIS IS NOT A DRIVEWAY LIGHT OUTPUT, Courtesy/Warning Lights Only




Push Button (WPB-PRESS/WPB-MHEAD)

Suitable for all applications a push button can be used to operate the gate simply by pressing the button.




Emergency Stop Button (WPB-STOP)

An emergency stop button is used typically if the system is in a manned operation such as a security office or gate house OR such applications where an internal door is automated.



ANT-5DB Antenna



The Antenna will assist with remote signal in a case where the signal has been blocked by the fencing or the gate. The antenna should be installed as high as possible allowing it to be visually seen over the fence line.

Remote Enrollment number	Users Name/Employee ID	Feature
01		
02		
03		
04		
05		
06		
07		
08		
09		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		

Warranty Terms and Conditions

The product is warranted for a period of twelve months (one year) from the date of purchase, unless expressly specified as extended warranty (extension to the warranty period). The product is to be installed for its intended purpose and for normal use as outlined within the installation manual, the product warranty is exclusively for defects in manufacturing and manufacturing workmanship. It does not cover out of guidelines use, natural or other disasters, abnormal weather conditions, damage incurred in shipping or handling, damage caused by disaster such as fire, flood, wind, earthquake, lightning, excessive voltage, mechanical shock, water damage, damage caused by unauthorized attachment, alterations, modifications, or foreign objects, damage caused by peripherals (unless such peripherals were supplied by Automation Systems Australia), defects caused by failure to provide a suitable installation environment for the products, damage caused by usage of the products for purpose other than those for which it was designed, damage from improper maintenance, damage arising out of any other abuse, mishandling, and improper application of the products.

At its discretion Automation Systems Australia will require the item determined by the support staff to be returned to base in its original unmodified condition for a warranty inspection if within the warranty period. A return authorization "RA" number will be provided to be enclosed with the product in question. The warranty will not cover freight fees to base, customs fees or any labour costs at the installation site but will cover repair or replacement of the product as seen fit. Automation Systems Australia will cover the freight of the returned item to the original address if deemed as a warranty repair or replacement item. Any warranty repairs or replacements continue to carry through the remaining warranty period and do not extend or restart the period.

Under no circumstances shall Automation Systems Australia be liable for any special, incidental, or consequential damages based upon breach of warranty, breach of contract, negligence, strict liability, or any other legal theory. Such damages include, loss of profits, loss of the product or any associated equipment, cost of capital, cost of substitute or replacement equipment, facilities or services, down time, purchaser's time, the claims of third parties, including customers, and injury to property.

This warranty contains the entire warranty and shall be in lieu of any and all other warranties, whether expressed or implied (including all implied warranties of merchantability or fitness for a particular purpose). And of all other obligations or purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning this product.

Automation Systems Australia will at its option repair or replace out-of-warranty products at a determined cost which are returned to its base according to the following conditions. Anyone returning goods to Automation Systems Australia must first obtain an authorization number. Automation Systems Australia will not accept any shipment whatsoever for which prior authorization has not been obtained. Products which Automation Systems Australia determines to be repairable will be repaired and returned. A set fee which Automation Systems Australia has been predetermined and which may be revised from time to time will be charged for each unit repaired. Products which Automation Systems Australia determines not repairable will be replaced by the nearest equivalent product available at that time. The current market price for the replacement product will be charged for each replacement unit.