




Always refer to Safety edge manual for fitting and precautions


Receiver Connection into Gate Controller



Transmitter Connection into Safety Edge

Wireless Transmitter

Transmitter remains
WITHIN
the Safety Edge Case



Pairing Safety Edge to Receiver

Pairing the Wireless Safety Edge

1. Press P1 **ONE TIME** and wait for the **single flash** from the LED.
2. Now press the press the safety edge to toggle the transmitters signal.

Receiver and Photocell Connection into Gate Controller (Series Circuit)

